

# SUPER DRY 3000

HELPS PREVENT SPOTTING BY CAUSING THE WATER TO FREE RINSE AND DRY WITHIN MINUTES. WATER TEMPERATURE BELOW 120 WILL CAUSE EXCESSIVE SUDSING. FOR BEST RESULTS SUPER DRY SHOULD BE USED at 140 degrees.

